

RECIPE

Spritz Cookies

From Mary Anne Barton

Ingredients

- 1 cup butter, softened
- ½ cup sugar
- 2 ¼ cup all-purpose flour
- 1 tsp salt
- 1 egg
- 1 tsp almond or vanilla extract
- Sprinkles

Preparation

1. Preheat oven to 400°F.
2. Beat butter and sugar in large bowl with electric mixer on medium speed, or mix with spoon (or two blunt knives).
3. Stir in flour, salt, egg, and vanilla extract (or almond extract if desired).
4. Place dough in cookie press. Form desired shapes on ungreased cookie sheet. Decorate with sprinkles.
5. Bake 5 to 8 minutes or until set but not brown. Immediately remove from cookie sheet to wire rack.